

HP InkJet Printers	HP Everyday Photo Paper		HP Advanced Photo Paper				HP Premium Plus Photo Paper				HP Iron-on Transfers	HP Social Media Snapshots	HP Professional Paper			HP ZINK® Sticky-backed Photo Paper	
	A4	10 x 15	10 x 15	13 x 18	A4	A3	10 x 15	13 x 18	A4	A3	A4	10x13	A4 120 g	A3 120 g	A4 180 g	A3 180 g	5 x 7.6 ²
	Q5451A Q2510A	CR757A	Q8691A Q8008A Q8692A	Q8696A	Q5456A Q8698A	Q8697A	CR677A CR695A	CR676A	CR673A CR674A CR672A	CR675A	C6050A	W2G60A ¹	Q6593A	Q6594A	Q6592A C6818A	C6821A	W4Z13A
HP ENVY 4520	•	•	•	•	•						•		•				
HP ENVY 5540 e-AIO	•	•	•	•	•						•		•				
HP ENVY 5640 e-AIO	•	•	•	•	•						•		•				
HP ENVY 7640 e-AIO	•	•	•	•	•						•		•				
HP Sprocket Photo Printer ³																	•

¹ Use with the HP Social Media Snapshot App and wireless / AirPrint / Google Print Plugin capable InkJet printers.
² For use with HP Sprocket Photo Printer only. Available in UK, Germany and Switzerland only.
³ HP Sprocket printer is only available in UK, Germany and Switzerland.

hp.com/go/learnaboutsups

