

HP InkJet Printers	HP Everyday Photo Paper		HP Advanced Photo Paper				HP Premium Plus Photo Paper				HP Non-on Transfers	HP Social Media Snapshots	HP Professional Paper				HP PageWide Bro GL SC Paper	HP ZINK® Sticky-backed Photo Paper ²	
	A4	10 x 15	10 x 15	13 x 18	A4	A3	10 x 15	13 x 18	A4	A3	A4	10 x 13	A4 120 g	A3 120 g	A4 180 g	A3 180 g	A4	A3	5 x 7.6
HP Officejet 5505/5510/5515	Q5451A Q2510A	CR757A	Q8691A Q8008A Q8692A	Q8696A	Q5456A Q8698A	Q8697A	CR677A CR695A	CR676A	CR673A CR674A CR672A	CR675A	C6050A	W2G60A ¹	Q6593A	Q6594A	Q6592A C6818A	C6821A	Z7567A	Z7568A	1DE37A 1RF37A ³
HP Officejet 5605/5607/5610/5615																			
HP Officejet J5730/J5780/J5785/J6410/J6415/J6424																			
HP Officejet 5740 e-AIO																			
HP Officejet 6100 ePrinter/6600 e-All-in-One/6700 Premium e-All-in-One																			
HP Officejet 6110																			
HP Officejet 6205/6210/6215																			
HP Officejet 6310/6315																			
HP Officejet K7100																			
HP Officejet 7210																			
HP Officejet 7310/7410																			
HP OfficeJet Pro 8210/8218																			
HP OfficeJet Pro 8710/8715/8718/8719																			
HP OfficeJet Pro 8720/8725/8730/8740																			
HP OfficeJet Pro 7740 WF																			
HP OfficeJet 7100 WF ePrinter/7510 WF/7610 WF eAIO/7612 WF																			
HP Officejet 9100 series																			
HP Officejet Pro K550/K5400																			
HP Officejet Pro L7480/L7580/L7590/L7680/L7780/K8600																			
HP Officejet Pro K850 series																			
HP Officejet Pro 8600 E-AIO/8600 Plus e-AIO/8610/8615/8620																			
HP Officejet Pro 8100 e-Printer (N811a)																			
HP Photosmart																			
HP PSC 500																			
HP PSC 1100/1200/1205																			
HP PSC 1210/1213/1215/1217/1219																			
HP PSC 1310/1311/1312/1315/1315s/1317																			
HP PSC 1340/1350/1355																			
HP PSC 1402/1410/1415/1417																			
HP PSC 1507																			
HP PSC 1510/HP PSC 1510s/HP DeskJet 1510																			
HP PSC 1600/1610																			
HP PSC 2105/2108/2110/2115/2175/2175/2179/2210																			
HP PSC 2350/2355/2355p																			
HP PSC 2410/2510																			
HP Fax 1220																			
HP Fax 3180																			
HP Photosmart 100/130/230																			
HP Photosmart 145/245																			
HP Photosmart 325/335/375/385/422/428/475																			
HP Photosmart A310/A314/A320/A432/A433/A436/A440/A441/A444/A516/A526																			
HP Photosmart A532/A612/A618/A626/A636/A646/A717/A826																			
HP Photosmart 1000/1100/1115/1215/1218/1315																			
HP Photosmart 2570																			
HP Photosmart 2575																			
HP Photosmart 2610/2710																			
HP Photosmart 3110/3210/3310/D6160/D7160/D7260/D7360/D7460																			
HP Photosmart C3170/C3175/C3180/C3190/C4180/C4190																			
HP Photosmart C4205/C4270/C4272/C4280/C4340/C4380/C4390/C4424/ C4472/C4480/C4485/C4524/C4580/C4585/C4599																			
HP Photosmart C4670/C4680/C4685/C4780																			
HP Photosmart C5180/C6180/C6270/C6280/C6285/C7180/C7280/C8180																			
HP Photosmart C5280/C5288																			
HP Photosmart C5324/C5380/C6324/C6380/D5460																			
HP Photosmart D5160																			
HP Photosmart D5360																			
HP Photosmart eAIO 5520, 6520 ¹²																			
HP Photosmart eAIO 5510/5515/6510																			
HP Photosmart 7150/7260/7345/7350/7450/7459/7550/7655																			
HP Photosmart 7510 eAIO																			
HP Photosmart 7520 eAIO ¹²																			
HP Photosmart 7660/7755/7760/7762/7960/7960pp																			
HP Photosmart 7850																			
HP Photosmart 8050																			
HP Photosmart 8150/8450/8450gp																			
HP Photosmart 8250																			
HP Photosmart 8750/8750gp																			
HP Photosmart Pro B8350																			
HP Photosmart B8550																			
HP Photosmart Pro B9180/B8850																			
HP Photosmart e-Station C510a																			
HP Photosmart B010a, B109a, B109d, B109f																			
HP Photosmart Wireless B109n/B110a/c/e																			
HP Photosmart Plus B209a, B209c, B210a/c																			
HP Photosmart Premium C309n/g, C310a																			
HP Photosmart Premium Fax C309a, C410b																			
HP Photosmart Ink Advantage K510a																			
HP ENVY																			
HP Envy 100 D410a																			
HP Envy 110 eAIO																			
HP PageWide																			
HP PageWide Pro 352dn/377dn/452dw/477dw																			
HP PageWide Pro 452dw/477dw																			
HP Sprocket Photo Printer																			

¹ Use with the HP Social Media Snapshot App and wireless / AirPrint / Google Print Plugin capable InkJet printers.

² For use with HP Sprocket Photo Printer only.

³ For Arabic countries.

hp.com/go/learnaboutsupplies

© Copyright 2017 HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

4AA2-5926EEE, July 2017

