



# HP ElitePad Serial Adapter

## We have an adapter for that!

PC ports. Minus the PC.  
Expand what you can do with your HP ElitePad, whether it's inside retail or out in the field. Attach barcode scanners, diagnostic tools, and more.\*



- Simply connect one end of the adapter to the HP ElitePad, and connect the other end to your serial device. Then pack and go when you're ready to disconnect.
- Get the peace of mind of a one-year limited warranty.

## HP ElitePad Serial Adapter



<b>Compatibility</b>	HP ElitePad
<b>Dimensions</b>	Out of Package: 148.9 x 15 x 38.77 mm Dimensions (case or master carton, metric): 380 x 460 x 290 mm Case or master carton quantity: 40 Minimum order quantity: 40 Count of cartons per pallet layer: 6 Count of layers in pallet: 5 Quantity per Pallet: 1200 Packed: 212 x 220 x 35 mm
<b>Weight</b>	Out of Package: 27.4 g Packed
<b>Warranty</b>	One-year HP limited warranty
<b>Additional information</b>	P/N: H3N50AA UPC/EAN code: 887111025654
<b>Country of Origin</b>	China
<b>What's in the box</b>	HP ElitePad Serial Adapter; Warranty card; Quick installation guide

\* Optional devices sold separately.

The product could differ from the images shown. © 2013 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

